# **Product Data Sheet**



# ASMACO CARBURETOR (CARB AND CHOKE) CLEANER

### **Product Description:**

ASMACO CARBURETOR CLEANER – highly effective carburetor cleaner without dismantling it. Quickly, carefully, and effectively cleans throttle and air dampers, diffusers, jets, and all other available internal surfaces of carburetors, as well as their external surfaces. Applicable to all two - or four-stroke gasoline engines, with or without catalytic converters.

### **Key Performance Properties:**

- It is a mixture of highly effective organic solvents. Does not contain acetone
- Completely dissolves and removes all typical carburetor contaminants of various origins
- Does not clog the engine components located behind the carburetor: valves, combustion chamber, etc.
- Stabilizes idle speed, facilitates cold start, improves engine acceleration
- Optimizes the operation of the intake system by cleaning and lubricating its moving parts
- The product contains substances that are aggressive to paint surfaces and plastics
- Reduces fuel consumption (up to 5%) and exhaust gas toxicity
- Applicable for cleaning motorcycle chains, timing chains, clutch parts, oil pumps, gears, crankshafts and other unpainted metal components and engine parts.

### **Applications:**

- Old and new vehicles and equipment
- Cars and trucks
- Tractors
- Motorcycles
- Boats

#### **Direction For Use:**

Turn off the engine, let it to cool down and remove the air filter. You need to get direct access to the throttle. Spray the product on all internal surfaces of the carburetor located in the access area, as well as, if necessary, on external surfaces. Let them dry. Replace the air filter in its original position. It is advisable to replace it at the same time. Turn on the engine and let it run at medium speed, and you can already start driving. You can also let the engine run at idle for 20 seconds at 2000 rpm, so that the remaining dirt in the injection system can burn. If the engine allows, i.e., can maintain a stable speed when the air intake is disconnected, then cleaning can be performed when the engine is turned on. If this doesn't work, contact the service center to find out how to do it. Sometimes it is enough to turn off the air flow meter. When the engine is running, the cleaning process is significantly intensified. At the same time, do not allow the product to get on the air flow meter and painted parts.



ASMACO
CARBURETOR
(CARB AND CHOKE)
CLEANER

## **Product Data Sheet**



### **Typical Properties:**

PROPERTIES	UNIT	SPECIFICATION
Appearance		Free flowing liquid
Colors		Water white
Odors		solvents
Specific gravity		0.81± 0.05
Pressure in can	Bar	$4.0 \pm 1$

### Storage and Shelf Life:

36 months when stored at 20°C / 50% relative humidity out of direct sunlight.

### Packaging:

ASMACO CARBURETOR CLEANER 400 ML - 12 CANS/CTN

### **Shipping Limitations: None**

#### Note

The information and data contained in the product data sheet is believed to be accurate and reliable; however, it is the user's responsibility to determine suitability of the product for usage. Since the supplier cannot know all the uses, or the conditions of use to which the product may be exposed, no warranties concerning the fitness or suitability for particular use or purpose are made. It is the user's responsibility to thoroughly test any proposed use of our products and independently conclude satisfactory performance in the application Likewise if the application, product specifications or manner in which our products are used require government approval or clearance, it is the sole responsibility of the user to obtain sure authorization.

Non – Warranty: Because the storage, handling and application of the material is beyond Anchor Allied Factory Ltd's control, we can accept no liability for the result obtained. Anchor Allied Factory Ltd's sole limited warranty is the product meets the manufacturing specifications in effect at the time of shipment. There is no warranty or merchantability or fitness for use, nor any expressed or implied warranty. Anchor Allied Factory Ltd will not be liable for any incidental and consequential damage of any kind. The exclusive remedy for breach of such limited warranty is a replacement of any product shown to be other than warranted. Suggestions of uses should not be taken as inducement to infringe any patents.







Tel. No.: +971 6 5342091, Fax No.: +971 6 5342107 P.O. Box No.: 21152, Sharjah (U.A.E.), E-mail : info@anchorallied.com.

SILICONE SEALANTS • WATERPROOFING COATINGS • PU SEALANTS • POLYSULPHIDE SEALANTS • ACRYLIC & DUCT SEALANTS POLYURETHANE FOAM • SPRAY PAINT • SILVER CLOTH DUCT TAPE • CREPE PAPER MASKING TAPE • ALUMINIUM FOIL TAPE P.E. PROTECTION TAPE • PVC PIPE WRAP TAPE • CONTACT ADHESIVE • EPOXY STEEL • PVC CEMENTS • SUPER GLUE

www.anchorallied.com \_\_\_\_\_\_ 2